

CZ Service Manuals

RiD90033i

CZ-R Unit Activation Procedure

Carbon Zapp -R Unit Activation Procedure

Requirements:

- □□ Machine, PCB, Tablet Serial Numbers >> Send first to CarbonZapp
- □□ USB Drive
- □□ .acf file << Received from CarbonZapp

When the following message appears, send the listed Serial Numbers to Carbon Zapp support, in order to receive the .acf file. If the PCB (Board) S/N is unknown, remove the panel of the PCB board, the S/N is printed on:



- 1. Save the .acf file on the root folder of the USB drive (e.g. D:\activation_000000001.acf)
 - IMPORTANT: Do NOT rename the file
 - IMPORTANT: Verify that the file on the USB ends in .acf, but NOT in .ACF (not capitals)
 - IMPORTANT: Verify the USB has ONLY 1 .acf file in it
- 2. Connect the USB Drive to the unit
- 3. Goto Home >> Settings >> Info >> Activation Code Status And Update and select Activate from USB

Below are some help screens for navigation purposes:







Main Offices & Production Plant

364 Varis-Koropiou Ave. Koropi 194 42 Athens, Greece

Headquarters

A.I.S. GmbH 75438 Knittlingen, Germany

email contact@carbonzapp.com **tel** +30 210 9856110 **fax** +30 210 9928655

carbonzapp.com